


LOCATION OF CONTROLS

1. RADIO DIAL SCALE
2. VOLUME CONTROL KNOB
3. FUNCTION (RADIO/TAPE) SWITCH
4. RADIO BAND SELECTOR SWITCH
5. RADIO TUNING CONTROL KNOB

6A. PAUSE BUTTON
6B. STOP & EJECT BUTTON
6C. FAST FORWARD BUTTON
6D. REWIND BUTTON
6E. PLAY BUTTON
6F. RECORDING BUTTON

7. SPEAKER
8. TELESCOPIC ANTENNA
9. BATTERY DOOR (BEHIND SET)
10. HEADPHONE (EARPHONE) SOCKET



## POWER SUPPLY

***BATTERY OPERATION***

- OPEN THE BATTERY DOOR AND INSERT 5 PCS "D-CELL" (UM-1/R20 TYPE) BATTERIES. PLEASE OBSERVE THE CORRECT BATTERY POLARITIES OR THE SET WILL NOT WORK.
- IMPORTANT: WHEN THE SET IS ONLY BEING USED WITH AC POWER OR NOT BEING USED FOR AN EXTENDED PERIOD OF TIME, REMOVE THE BATTERIES TO PREVENT LEAKAGE OR DAMAGE.

***AC OPERATION***

- MAKE SURE THE SET VOLTAGE OF THE UNIT MATCHES YOUR LOCAL HOUSEHOLD VOLTAGE.
- INSERT THE TAIL-END OF THE AC-CORD INTO THE AC-SOCKET AT THE REAR OF THE SET.
- INSERT THE PLUG OF THE AC-CORD INTO THE WALL OUTLET WITH AC-POWER.

## OPERATION OF RADIO

- SET THE FUNCTION SWITCH TO "RADIO" AND THE BAND SELECT OR SWITCH TO THE DESIRED BAND.
- ROTATE TUNING KNOB TO TUNE-IN THE DESIRED STATION.
- ADJUST THE TELESCOPIC ANTENNA AND POSITION THE SET TO OBTAIN THE BEST RECEPTION.
- ADJUST THE VOLUME KNOB TO THE DESIRED LEVEL.
- TO TURN OFF THE RADIO. SLIDE THE FUNCTION SWITCH TO "TAPE" (OFF) POSITION, WITHOUT ANY TAPE BUTTON PRESSED.

## CASSETTE TAPE PLAYBACK

- SLIDE THE FUNCTION SWITCH TO THE "TAPE" POSITION.
- OPEN THE CASSETTE DOOR BY PRESSING THE "STOP/EJECT" CASSETTE BUTTON.
- INSERT A PRERECORDED CASSETTE WITH THE TAPE SIDE UP, INTO THE PROPER GUIDE RAILS ON THE INSIDE OF THE CASSETTE DOOR.
- GENTLY PUSH THE CASSETTE DOOR FORWARD (INWARDS) TO CLOSE IT. MAKE SURE THE TAPE IS FULLY AND PROPERLY INSERTED BEFORE DOING SO.
- PRESS THE CASSETTE PLAY BUTTON TO START PLAYBACK. NOTE THAT THE TAPE MOVES FROM RIGHT TO LEFT.
- ADJUST THE VOLUME TO THE DESIRED LEVEL.
- THE TAPE PLAYBACK CAN BE STOPPED BY PRESSING THE "STOP" BUTTON. WHEN THE TAPES HAS ENDED, THE SET SWITCHES ITSELF OFF AUTOMATICALLY AND RELEASES THE PLAY BUTTON.
- PRESS THE "STOP" BUTTON FOLLOWED BY THE "REWIND" OR "FAST-FORWARD" BUTTON TO REWIND OR FORWARD THE TAPE AT HIGH SPEED.

## CASSETTE TAPE RECORDING

- OPEN THE CASSETTE DOOR BY PRESSING THE "STOP/EJECT" CASSETTE BUTTON.
- INSERT A BLANK CASSETTE WITH THE TAPE-SIDE UP, INTO THE PROPER GUIDE-RAILS ON THE INSIDE OF THE CASSETTE DOOR.
- GENTLY PUSH THE CASSETTE DOOR FORWARD (INWARDS) TO CLOSE IT, MAKE SURE THE TAPE IS FULLY AND PROPERLY INSERTED BEFORE DOING SO.
- THE SET IS NOW READY TO START RECORDING. WHICH CAN BE DONE FROM EITHER LIVE SOURCE OR THE RADIO.

RECORDING FROM RADIO
- SLIDE THE FUNCTION SWITCH TO "RADIO" POSITION.
- TUNE IN THE DESIRED STATION BY TURNING THE TUNING KNOB IF NECESSARY, EXTEND THE TELESCOPIC ANTENNA, AND ADJUST POSITION OF THE SET TO IMPROVE RECEPTION.
- PRESS THE PLAY AND RECORD BUTTONS TOGETHER.
- DUE TO THE "ALO" FUNCTION (AUTOMATIC LEVEL CONTROL) NO FURTHER ADJUSTMENTS ARE REQUIRED. THE VOLUME CONTROL WILL NOT AFFECT THE RECORDING.

## PRESERVATION OF RECORDINGS

- TO PREVENT ACCIDENTAL ERASURE OF CASSETTES, SIMPLY BREAK OFF THE TWO PLASTIC TABS LOCATED ON THE REAR EDGE OF THE CASSETTE. WHEN A CASSETTE WITH REMOVED PLASTIC TABS IS INSERTED, THE RECORDING BUTTON CANNOT BE DEPRESSED.
- IF A CASSETTE IS TO BE ERASED AND RE-RECORDED AT A LATER STAGE, SIMPLY COVER THE HOLES ON THE CASSETTE WHERE THE TABS WERE REMOVED, WITH A PIECE OF STRONG ADHESIVE TAPE.

SPECIFICATIONS
POWER SUPPLY: ..... AC110V OR 220V 50/60Hz
DC7.5V = 5X"D" (UM-1/R-20) SIZE
BATTERIES (NOT INCLUDED)



# COBY

## OPERATING INSTRUCTIONS



## CX-244 AM/FM STEREO CASSETTE PLAYER/RECORDER

COBY®

# 90 DAY LIMITED WARRANTY

**COBY ELECTRONICS CORP ("COBY")** warrants this product to the original purchaser to be free from defects in material or workmanship under normal use for 90 DAYS from the date of original purchase. **COBY** agress under this warranty, to repair or replace it with a new or reconditioned product at no additional charge. Our warranty does not cover any product which has been subject to neglect, unreasonable use, accident, violation of operating instructions, or any product that has been repaired or modified by an unauthorized service agent.

To obtain factory service, return this unit freight-prepaid to the address shown below within the duration of this warranty. Enclose $6.00 for each item in form of money order made payable to **COBY ELECTRONICS CORP**. To cover the cost of shipping and handling. Also include a copy of the sales receipt to show proof of purchase and a detailed description of the problem. The unit(s) must be packaged in such a way as to reasonably protect it from possible shipping damaged. For further information write to:

**COBY ELECTRONICS CORP.**
**Customer Service Dept.**
**56-65 Rust Street**
**MASPETH, NY 11378**

**COBY**'s liability under any legal theory for any loss or damage in any way related to this product shall not be exceed the sales price of this product. In no event shall COBY be liable for any incidental or consequential damages resulting from the use of this product, or inability to use this product. Repair of replacement as provided under this warranty is the exclusive right of the consumer.

Except to the extent prohibited by law, no express or implied warranty of merchant ability or fitness for a particular purpose on this product shall be extended beyond the period of this warranty. Some States prohibit the exclusion or limitation of incidental or consequential damages, so that the above limitations or exclusion may not apply to you. This warranty gives you specific rights, and you may also have other rights that may vary from State to State.